






**Инструкция по сборке
E5502.0000.0000**



Таблица 1 — Составные части оборудования

 <p>E5502.0001.0000 — 1 шт</p>	 <p>E5502.0002.0000 — 1 шт</p>	 <p>E5502.0009.0000 — 1 шт</p>	 <p>E5502.0011.0000 — 1 шт</p>	 <p>SH12.100.D571 (Винт самонар., с шестигр. головкой, 12×100, DIN 571) — 6 шт</p>
---	--	---	---	---






Рисунок 1

E5502.0011.0000



E5502.0009.0000



SH12.100.D571




Рисунок 2




Рисунок 3