

Инструкция по сборке
E8105.0000.0000







Таблица 1 — Составные части оборудования

 <p>0000.7422.0000 — 1 шт</p>	 <p>E8105.0000.S001 — 4 шт</p>	 <p>SH12.100.D571 (<i>Винт самонар., с шестигр. головкой, 12×100, DIN 571</i>) — 15 шт</p>
--	--	---




Рисунок 1