

Инструкция по сборке  
**E8109.0000.0000**






Таблица 1 — Составные части оборудования

		
E8109.0001.0000 — 1 шт	E8109.0000.S001 — 8 шт	SH12.100.D571 ( <i>Винт самонар., с шестигр. головкой, 12×100, DIN 571</i> ) — 33 шт





Рисунок 1


Вид сверху

Установка стоек и стола  
согласно схеме скважин.



E8109.0000.S002

E8109.0002.0000



SH12.100.D571




Рисунок 2